

# MISCELLANEOUS PARTS

## INSTALLATION INSTRUCTIONS

### SERVO EXTENDO PINS

for 200, 440-T4, 700-R4,

**AXODE LOW & INTERMEDIATE, A4LD REVERSE ONLY**

**56605E: A4LD Reverse Only**

**65786E: 200, 200C, 200-4R, 325, 325-4L**

**77605E: 700-R4**

**77605G: 4L60E**

**84572E: 440-T4 (Fits 1-2 & Reverse)**

**96946E: AXODE Low & Intermediate**



1. Determine the amount needed to be added to your pin application by whatever means you normally use.

**Extendo-Pin length extends pin length as follows:**

440-T4	.300
700-R4	.150
4L60E	.289
200	.125
A4LD (Reverse Only)	.190
AXODE (Low & Int.)	.200

2. Place the Extendo-Pin on the band-apply end of the servo pin. Use a hammer to strike the tip of the Extendo-Pin and drive the tip until it bottoms (two or three strong hits) (**Figure 1**).

3. Now the pin can be ground to the desired length (**Figure 2**).



Figure 1

Figure 2



**NOTE:** Blow or wash excess grinding debris from servo.

Revised 9/20/03