

INSTALLATION INSTRUCTIONS

Part# 262125LB

Axle Stabilizer

For Chrysler 62TE

1. Remove the axle from the vehicle.
2. Remove the axle seal.
3. Check that the taper roller bearings supporting the ring gear are in good shape.
4. Clean the area where the seal was removed.
5. Place Blue Lock-Tite on the knurl and Blue Silicone on the corner that will be against the case of the axle stabilizer.
8. Install the stabilizer until it bottoms against the case. You will know because the silicone will flatten against the case.
9. Reinstall the axle.

Teckpak Hotline: 1-800-527-2544
www.teckpak-fitzall.com