

# INSTALLATION INSTRUCTIONS

## SHIFT SOLENOID



**56841U** OEM Compatible Plugs

### **\*NOTE:**

Use care when removing solenoids, valve may fall out and become damaged.

### **TO REMOVE:**

**1. Label wires solenoids are positioned as follow:**

Passenger side SSC & SSA front to rear respectively, drivers side solenoid order TCC, SSD/CCS, SSB, EPC, front to rear unit.

**2.** Remove filter to expose bolt's holding bracket, loosen and remove bracket. Now unplug harness and remove solenoid.

**3.** Reinstall in reverse manner, torque bolts to factory specifications and replace filter.

***Teckpak Hotline: 1-800-527-2544 / [www.teckpak-fitzall.com](http://www.teckpak-fitzall.com)***