

KTC4981
MADE IN THE U.S.A.



FITZall

CHRYSLER SHIFT CABLE REPAIR ASSORTMENT KIT

**Kit Contains: 5 Different
Chrysler/Dodge/RAM/Jeep Shift Cable Grommets**

C92498-1



C82498-1



C72498-1A



C72498-1B



C22498-TND



KTC4981

INSTALLATION INSTRUCTIONS

Made to repair Chrysler shifter cables with plastic linkage to the shift lever of the transmission.

All Chrysler Grommets require drilling out the old grommet except the C22498-TND does not require drilling.

Common Applications

C92498-1
40TE, 41TE, 41TES
62AE, 62TE
2002-2020
2009-2020

C82498-1
42LE
2003-2010

C72498-1A
45RFE
42RE, 46RE, 47RE, 48RE
545RFE
NAG 1
W5A580
2002-2003
2002-2004
2003-2006
2006-2014
2011-2020

C72498-1B
545RFE, 645RFE
65RFE, 66RFE, 68RFE
AS66RC, AS69RC
2012-2014
2014-2024
2012-2024

C22498-TND
Transfer Case
NP241, NP271, NP273

2002-2022

Instructions

1. Confirm this part is correct for your application by comparing the **height of the grommet** to the **thickness of the cable end**. If the space between the base and the teeth of the grommet, you are likely correct.
2. Use the **13/32 drill bit** on all applications except those with  in the Common Applications section. Drill through the damaged shift cable grommet and hole to create a **clean straight hole without debris**.
DO NOT DRILL THE CABLE FOR THE C22498-TND
3. Clip this repair grommet into the cable with the solid/smooth base ring of the grommet facing the lever arm.
4. Snap the cable onto the pin of the shift lever arm.



Fitzall Support:
1-800-527-2544
www.fitzall.com