

KTF4981
MADE IN THE U.S.A.



FORD SHIFT CABLE REPAIR ASSORTMENT KIT

Kit Contains: 6 Different
FORD Shift Cable Grommets

F36498-1



F56498-1



F76498-1



F96498-1



F46498-1ND



F49498-1ND



7 57738 23005 5

KTF4981

INSTALLATION INSTRUCTIONS

Made to repair Ford shifter cables with plastic linkage to the shift lever of the transmission.

All Ford Grommets require drilling out the old grommet except the specified "No Drilling Required" parts.

Common Applications

F36498-1
4R70E, 4R75E, 4R100 1999-2005
6F50, 6F55 1997-2005
ECVT(HP35) 1996-2001

F56498-1
4R44E, 4R55E 1995-1996
5R44E, 5R55E 1997-2005
AX4S, AX4N, 4F50 1996-2001

F76498-1
E40D, 4R70, 4R75, 4R100 1997-2019
5R55S, 5R55W 2002-2010
5R110W 2006-2019
DPS6 2011-2018
6F50 2012-2018
6R60, 6R80 2006-2019

F96498-1
4F27E 2000-2003
CD4E 2001-2007
6F15 2016-2018
DPS6 2015-2019
6R140 2011-2016

F46498-1ND
No Drilling Required
6F35, 6F50
8F35 2012-2019
2018-2023

F49498-1ND
No Drilling Required
4F27E
4R70W, 4R75W
6R80 2005-2011
2005-2014
2011-2019

Instructions

1. Identify the part needed for your application. All parts with an **ND at the end** of their part number **do not require drilling**. Special instructions for these can be found on the inside of this label.
2. Confirm this part is correct for your application by comparing the **height of the grommet** to the **thickness of the cable end**. If the space the part will occupy fits between the base and the teeth of the grommet, you are likely correct.
3. Some parts require drilling:
13/32 drill bit:
 - F36498-1
 - F76498-1
 - F96498-1**15/32 drill bit:**
 - F56498-1

NO DRILL:
Have this  by them in the Common Applications section.

Drill through the damaged shift cable grommet and hole to create a **clean straight hole without debris**.
DO NOT DRILL THE CABLE FOR THE F46498-1ND & F49498-1ND

4. Clip this repair grommet into the cable with the solid/smooth base ring of the grommet facing the lever arm.
5. Snap the cable onto the pin of the shift lever arm.



Fitzall Support:
1-800-527-2544
www.fitzall.com

Ford Grommet Instruction Guide

Made to repair Ford shifter cables with plastic linkage to the shift lever of the transmission.

Please follow the instructions:

No Drill Application



F49498-IND



F46498-IND



F76498-1

**F76498-1
Special Instructions**

KTUSA4981

Get this kit and more in our
Complete Domestic Shifter Grommet Repair Kit
34 Grommets in 1 Comprehensive Kit



Special Instructions

No Drill Parts

- All parts with an **ND** at the end of their part number do not require drilling.
- You may use the **13/32** drill bit to clean the broken grommet from the hole.

Note: With **F49498-1** if you choose to use the drill ensure that you do not remove the internal ledge inside the adjuster.

F76498-1

- Slide up the outer cover of the adjuster and remove but do **not discard** as you will need to put it back on.
- Drill through the inner part of the adjuster.

Note: The repair grommet is inserted so that the teeth of the repair grommet are facing the shift lever arm. Additionally, the grommet must be oriented with the widest finger facing up so the outer sleeve will touch it first when reinstalled

Contact us for more information:

1 573 785-1411
1 800 527-2544

info@fitzall.com

fitzall.com

