

INSTALLATION INSTRUCTIONS

Instruction sheet for P56PIN3MM

Quick Release Ford Manual Lever Retaining Pin

For: A4LD, AOD, AODE, 4R44E, 4R55E, 5R55E, and E4OD

Note: There are two different sizes of pins used in the above units. It will be necessary to try the 3MM pin first and if it falls out the unit requires the 1/8 inch pin. The 3MM pins are colored black while the 1/8 inch pins are grey colored.

- 1. Remove the original manual lever retaining pin. This can be assisted with the use of tool # TK56RTD.**
- 2. Installing the pin: When installing the pin make sure you have the right size pin as mentioned in the above note. Insert the pin with the tapered into the hole and the head end out.**

Removal of the Quick Release Ford Manual Lever Retaining Pin:

- 3. The pin will come out much easier than the OEM pin. It will require a small pair of pliers but will come out with two small tugs on the pins.**