

INSTALLATION INSTRUCTIONS

Radiator Cooler Line "Repair" Fitting

T16996XR - FORD 3/8" Push-in Line ('02 & up)

T16996ZR - FORD 1/2" Push-in Line ('02 & up)



1. Remove the old cooler line fitting - **ONE AT A TIME ONLY**. **If you remove both fittings at the same time you will drop the inner cooler into the radiator.**
2. Thread the new fitting into the radiator. **Do NOT use thread sealer or tape on the threads.** Torque fitting to 28 - 33 ft-lb.
3. Push the cooler line into the compression fitting until it bottoms and while holding it against the fitting tighten the compression nut until snug.
4. Place a wrench on the fitting to keep it from turning and finish tightening the compression nut.

