FIXALL™ TOOLS

INSTALLATION INSTRUCTIONS

CARRIER BEARING REMOVER TOOL

CHRYSLER FWD CARRIER BEARING REMOVER & INSTALLER

EASY STEP-BY-STEP INSTALLATION

An inexpensive solution for customers with older, less expensive vehicles, as well as a more efficient way of providing service to your late-model customers. An opportunity to expand your customer base in both directions.

T604-306



Unbolt carrier bearing retainer.



Remove carrier bearing retainer.



PART #10219 is the replacement O-ring

Inspect carrier bearing race.



"10-Minute Solution"

T604-305

Install magnetic cage and roller retainer



Cut cage of carrier bearing.



Remove magnet cage and roller retainer and discard old rollers and cage.



Push tool over carrier bearing cone until it clicks.



Use your 1/2" impact to remove carrier bearing cone from final drive.



Use small screw driver to remove carrier bearing cone from tool.



New carrier bearing is placed over installation arbor.



Collar and carrier bearing are pushed into final drive.



Place carrier bearing installer/ remover tool into bearing arbor and bolt bracket to case.



Use your 1/2" impact to force the carrier bearing onto the carrier.



Install the new carrier bearing race. Do not use the oil splash shield when using Teckpak's Axle Stabilizers.



Install the Teckpak/Fitzall Stabilizer bearing.



Reinstall the carrier bearing retainer. You have now rebuilt the final drive tighter than OEM. with the "10-Minute Miracle."



CHRYSLER FRONT-WHEEL DRIVE CARRIER
BEARING REMOVER AND INSTALLER
T604-306


"10-MINUTE SOLUTION"

Now you can understand how easy it really is!

The TECKPAK/FITZALL Bearing Remover/Installer

Available from distributors worldwide!

- ◆ Installs in the vehicle or on the bench.
- Same large bearing used on either side.
- Installs as easy as an axle seal.
- ◆ Chrysler, GM NOW AVAILABLE!



AXLE STABILIZER
INSTALLATION DRIVER

T404-303