

INSTALLATION INSTRUCTIONS

Part# T74498-1C

Shift Cable Repair End (Grommet)

Fits: GM Shift Cables that Snap onto a "Ball" or "Bell" shaped pin.

- 1. Using 13/32" drill bit, drill out the broken pieces of the old clip from the cable end. (Fig. 1)**
- 2. Install the new clip into the shift cable. (Fig. 2 & 3)**
- 3. Snap the cable onto the shift arm.**
- 4. Check the connection to insure that the clip is secure.**

NOTE: For use on "Ball" and "Bell" shaped shafts. (Fig. 4)



Teckpak Hotline: 1-800-527-2544
www.teckpak-fitzall.com