

INSTALLATION INSTRUCTIONS

Part# T92498-T2

Transfer Case Repair Grommets

**Fits: ('02-'12) Chrysler, Dodge & Jeep
(Replaces the old rubber style grommets)**

- 1. Snap the outer portion of the grommet into the hole in the shift lever and then attach the linkage rod assy. (Fig. 1).**

FIG. 1

