

INSTALLATION INSTRUCTIONS

Part# 84125LB 91

GM Axle Stabilizer

**For GM 4T60E / 65E
(Left Side Only)**

- 1. Remove the axle.**
- 2. Remove the axle seal.**
- 3. Clean the area where the seal was removed.**
- 4. Place Blue Lock-Tite on the knurl and Blue Silicone on the corner that will be against the case of the axle stabilizer.**
- 5. Install the stabilizer until it bottoms against the case. You will know because the silicone will flatten against the case.**
- 6. Reinstall the axle.**

Teckpak Hotline: 1-800-527-2544
www.teckpak-fitzall.com